

# EXOv5 Ultra Hydrophobic Coating - Application Information

## Storage and Use

- To apply EXOv5 make sure your vehicle is indoors and can stay indoors for 12 hours after application, do not apply in direct sunlight
- Note.. EXOv5 is a single layer application
- Only apply the product at a temperature between 5°C and 25°C
- Shake well and wear gloves
- If using as a stand alone coating, wash and decontaminate your paintwork thoroughly prior to application. If required, polish your paintwork, either by machine or hand, to remove any imperfections
- Spray Panel Wipe onto a Gtechniq MF1 Microfibre Cloth and wipe down each panel in small sections
- Soak the application pad with EXOv5 and work the liquid into the pad to get an even saturation
- Replace the lid on the bottle and set aside - do not keep the bottle in your hand as this promotes premature curing
- Apply in overlapping strokes to an area roughly 2ft by 2ft (60cm by 60cm), or work to the bodylines of the vehicle
- After approximately 1 to 2 minutes remove the residue with a Gtechniq MF1 Cloth - you may need to buff the same area several times, however, avoid doing it with too much force. We recommend the use of 2 cloths at any one time. Make sure the cloths are rotated during residue removal to prevent EXOv5 curing in the cloth - this can make buffing residue difficult
- Inspect the surface for excess residue with a bright, diffused light source
- If you do not remove all the excess residue and it cures fully then you should polish the area and reapply EXOv5
- As soon as you finish, put your MF1 cloths in water, wash and dry them as soon as possible – never re-use an already used MF1 cloth for ceramic coatings
- If you are overcoating Crystal Serum Light with EXOv5 then wait approximately 1.5 to 2 hours after you have applied CSL to apply EXOv5, or C2v3 Liquid Crystal
- If you are overcoating C1 Crystal Lacquer with EXOv5 wait a minimum of 4 hours after you have applied the C1 Crystal Lacquer to apply EXOv5, or C2v3 Liquid Crystal
- Store EXOv5 in a cool, dry place
- Use within 3 months of opening ensuring original cap is re-applied.
- **Do not apply EXOv5 directly to rubber, hard plastics, head lights or tail lights**
- Refer to the Gtechniq Australia YouTube channel for all of our how to apply videos:-

Scan here:-

